


- Ⓓ Torsionsfederwelle vorneliegend VL
- ⒼⒷ Front-mounted torsion spring VL
- Ⓕ Arbres à torsion à l'avant VL
- ⒼⓁ Torsieveeras aan de voorzijde VL



- Ⓓ B = Bodensektion
- S = Schlosssektion
- M = Mittelsektion
- K = Kopfsektion

- ⒼⒷ B = bottom section
- S = lock section
- M = middle section
- K = top section

- Ⓕ B = section basse
- S = section de serrure
- M = section centrale
- K = section haute





- ⒼⓁ B = bodemsectie
- S = slotsectie
- M = middensectie
- K = kopsectie







Ⓓ Bildteil aus Montageanleitung entnehmen




ⒼⒷ Remove the illustrated section from the installation instruction






Ⓕ Illustrations: voir notice de montage








ⒼⓁ Zie de montageaankwijzing voor de illustratie








































S10 S5;S12 56;61 48R



S10 68 S10




c



da

80



db




80




S14







S10






79












- Ⓓ **Torsionsfederwelle hintenliegend HL**
- ⒼⒷ **Rear-mounted torsion spring HL**
- Ⓕ **Arbre à torsion à l'arrière HL**
- ⒶⒶ **Torsieveeras aan de achterzijde HL**









- Ⓓ **B = Bodensektion**
- S = Schlossektion**
- M = Mittelsektion**
- K = Kopfsektion**


- ⒼⒷ **B = bottom section**
- S = lock section**
- M = middle section**
- K = top section**

- Ⓕ **B = section basse**
- S = section de serrure**
- M = section centrale**
- K = section haute**


- ⒶⒶ **B = bodemsectie**
- S = slotsectie**
- M = middensectie**
- K = kopsectie**








- Ⓓ Schadenfall Federbruch
- ⒼⒷ Damage claim: spring fracture
- Ⓕ Dommage rupture de ressort
- ⒼⓃ Schade veerbreuk



a




b



ca




cb




cb-a



cc



d



e



- D** Einzelteilliste für Sektionaltore
mit Torsionsfederwelle
(vorneliegend - VL, hintenliegend - HL)
- GB** Part list for sectional doors
with torsion spring
(front-mounted - VL, rear-mounted - HL)
- F** Liste des pièces individuelles pour portes
sectionnelles avec arbre
de ressort à torsion
(à l'avant - VL, à l'arrière - HL)
- NL** Lijst met reserveonderdelen voor
sectiedeuren met torsieveeras
(aan de voorzijde - VL, aan de achterzijde - HL)

VL + HL

1_L



42661 ...

1_R



42661 ...

3



65318 ...

4_L




30501315

4_R



30501316

6



65391 ...

7



11400017

13



30475000

14_R










42500 ...

14_L







42500 ...



VL + HL

16L  11500010	16R  11500011	18  30592002
19  30592001	20  30281001	
21L  30501019	21R  30501020	27  82550002
28  30085000	29  30059000	30  42000001
35R 	35L 	
37  65340000	38  65330000	39  11910209




VL + HL














44  B	45L  11100041	
45R  11100042	47  660080 ...	48R  36004003
48L  36004002	49  36009001	56  36010001
57R  36002002	57L  36002001	58  11100030
59  30462000	60  30501204	61  36006001
67  S	68  36004001	

VL + HL

69  64535 ...	70  30545002	71  30546002
72  30546011	73  30539001	74  11200009
75  11100021	76  64581000	77  30540000
78  64565000	79  30503010G	80  65977 ... 65978001 f. Kass.
86  M	87  K	
88  11400075	89  11400062	90  11400076

VL + HL

91  11400065	92  30107000	93_R  30503012
93_L  30503011	94  30503013	95  11100011
96  65170 ...	97  30501010	98_L  30501011
98_R  30501031	100  11400066	101_R  10400002G
101_L  10400001G	103  11400041	104  30089...
105_L  11400070	105_R  11400069	106  36103001

S1 Ø4x38 30541000 	S8 Ø8x50 11000090 
S2 M5x30 64513000 	S9 Ø10x50 30255000 
S3 Ø4,2x25 30542000 	S10 Ø6,3x16 80161009 
S4 M5x30 - 	S11 M8x14 11000091 
S5 M8x16 30536000 	S12 M8 80153000 
S6 M8x13 30317000 	S13 M8x18 11000006 
S7 Ø6,3x10 	S14 M6x10 11000056 
S15 M8x12 11000095 	Ø4,2x9,5 11000092 
U1 8,4x24x2 