

Intelligent Door Solutions

Novoferm GmbH, Feineisenstr. 5, 44339 Dortmund

Important documents iso70 sectional garage door with RC2 hardware

Please note and keep!

Novoferm GmbH

Feineisenstr. 5, 44339 Dortmund Telefon: (0231) 8299-500, Telefax: (0231) 8299-502 Info: 0800-66 86 33 76 (Novoferm) E-Mail: vertrieb@novoferm.com Internet: www.novoferm.com

iso70 Premium Plus sectional garage door with RC2 burglar resistance

You have received a Novoferm quality sectional garage door with burglar-resistant resistance class RC2 according to DIN/TS 18194:2020-07.

Please find enclosed with this letter the associated identification label, which must be permanently attached next to the type plate on the door leaf after installation. Please ensure that the label is not accidentally removed or becomes illegible due to external influences or cleaning measures.

Please note that resistance class **RC2** according to **DIN/TS 18194** can only be achieved if the following conditions are met:

- The Novomatic 563 S or Novomatic Speed (N-573S) garage door operator has been installed (no NovoPort)
- The door leaf area (BRB x BRH) is a maximum of 12 m²
- The head section is designed without a special sectional height (not possible: BRH 2150 2225 & 2675)
- The support brackets supplied have been fitted in the lower area of the frames on the left and right in accordance with the instructions
- No other openings have been made in the door leaf, such as: window variants, emergency unlocking mechanisms, door locking mechanism incl. lock and handle, and ventilation grating
- Assembly with thermo frame set only possible from version 2 (since 09/2022)
- The building structure's opening dimension must correspond to the door's coordinating height. The door should be an exact fit and must not offer any point of attack due to the installation situation. (max. WOM (wall opening dimensions) = BRM (coordinated size) + 10 mm all round = (BRB [coordinating width] +20) x (BRH [coordinating height]+10)
- Only installation behind the opening and fixing through frame front holes → reinforced angular frame, panels and special anchors cannot be used
- No use of key switches

Deviations from the above specifications will **invalidate the RC2** class.

In case of deviations, the sticker must not be applied to the door leaf.

Installation in compliance with the specifications must be documented by a specialist contractor's confirmation, which must be kept together with this letter and the installation and operating instructions.

Please contact your Novoferm dealer if you require any further information.

Your Novoferm team